



Fiberglas-Teleskopmaste

Best.-Nr 18338.xx



Low-Cost Fiberglas-maste

Unsere einfachen Fiberglas-maste haben dieselbe Biegesteifigkeit wie das Original, jedoch keine Friktionszonen und Verstärkungsringe, und werden ohne Stoffsack geliefert. Länge eingeschoben 1m.

Best.Nr. Länge ausgezogen

18338.04	4m
18338.06	6m
18338.10	10m

Aufbau:

Die Segmente werden durch auseinanderziehen und gleichzeitiges Drehen verriegelt.

Bitte keine Gewalt anwenden... auch ohne Gewalt halten die Segmente durch die Keilwirkung gut. Wer Bedenken hat, kann mit Klebeband sichern.

Oben anfangen: Kappe abnehmen und zuerst das oberste Element ausziehen und verriegeln. Dann Stück für Stück die nächsten Segmente ausziehen und verriegeln.

Nicht benötigte Teile müssen unbedingt entnommen werden, weil sie sich sonst zwischen den anderen Teilen verklemmen könnten!

Bruch wäre die Folge. Zum Entnehmen den Schraubverschluss unten öffnen.

Abbau:

unten anfangen: das zweite Rohr von unten in das unterste Rohr zurückgleiten lassen und so weiter. Nicht oben anfangen... das oberste Rohr würde nach unten fallen und evtl. splintern, und außerdem durch die nachfolgenden Rohre beschädigt werden.

An den Enden gesplitterte Rohre sind immer ein Zeichen für Handhabungsfehler und deshalb kein Garantiefall... bei bestimmungsgemäßer Verwendung können die Rohre an den Enden nicht splintern.

Naß abgebaute Maste bitte vor dem Einlagern auseinanderbauen und trocknen.

Die Maste halten am Besten wenn die Rohre sauber sind... Sand/Staub etc. deshalb von Zeit zu Zeit entfernen, dazu am besten den Mast komplett zerlegen (Rohre nach unten entnehmen).

Viel Vergnügen mit dem Fiberglasteleskopmast!

Handling instructions

Remove for the upper rubber plug and shake out the thinnest (center) section. Continue with the next section. Always begin with the thinnest section!

By pulling and simultaneously twisting the tubes the cone locks very tight. Do not overtighten however!

If you don't need the upper thin sections it is required to remove them from the mast by opening the screw-type cap bottom cap. If you don't take them out there is quite a big risk that the thinnest section gets blocked between the other sections! Also down-moving parts will be damaged because they will hit the loose inner sections.

Please note that defect due to misuse are not a reason for warranty claims.

Mishandling can be determined easily if the lower section has cut itself into an upper section and/or the metal ring are lost or damaged.

Collapsing the Mast:

start with the lowest (thickest) section. While rotating the two parts against each other, apply little pressure only however, in order to avoid getting your fingers jammed if the grip suddenly looses.

If the mast had to be collapsed when wet, we recommend to disassemble it fully and dry all parts before storing.

A clean mast locks best... avoid sand, dust and mud between sections. The whole mast should be cleaned from time to time with soap water. Do not use acetone or other aggressive cleaners.

Wishing much pleasure with your fiber glass telescope mast!

WiMo Antennen und Elektronik GmbH

Am Gäxwald 14, D-76863 Herxheim Tel. (07276) 96680 FAX 9668-11

<http://www.wimo.com>

e-mail: info@wimo.com