RV-3 = SM-empfang
RV-1 = Squelch Frontf.
CT-1 = Sende freq.
RV-4 = SM-Sende
RV mster = Mod

Schealtbild 812M Twin Mod



NOTE
ΔVOLTS AT TRANSMIT CONDITION
ALL VOLTAGES MEASURED FROM PC BOARD GND WITH DC VTVM AT NO SIGNAL (AT 13.2V POWER SUPPLY) IF MEASUREMENT VALUES OBTAINED ARE IN EXCESS OF ±20% OF VALUES SHOWN THEN REASON FOR DIFFERENCE SHOULD BE CORRECTED
⏚ CHASSIS GND ⏚ PC BOARD GND
* VARIABLE